



EFS-EC2

Wiring diagram



Place fuse between truck battery and NATO connector. Install fuse close to the battery!



Article number	Component	Firmware article number	Firmware version
619730	Bluetooth module ext. Antenna	910009	BD.00.08
615126	Bluetooth module int. antenna	910009	BD.00.08
614224	CAN I/O module	910011	BD.01.05
313926	Concentric Pump Controller	n.a.	n.a.
620372	Kikker	n.a.	n.a.
615871	Main Control Unit	910013	BD.02.36
617403	Remote Control	910028	BD.01.32

